

ARM RESTRAINT INSTALLATION INSTRUCTIONS

THANK YOU FOR PURCHASING A SET OF ZAMP ARM RESTRAINTS. PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT. ALL ZAMP ARM RESTRAINTS MEET OR EXCEED SFI STANDARDS.

THIS RESTRAINT SYSTEM IS DESIGNED AS AN ATTEMPT TO RESTRAIN THE ARMS FROM GOING OUTSIDE THE RACE CAR IN THE EVENT OF A CRASH OR ROLLOVER WHERE INJURY COULD RESULT TO ARMS OUTSIDE THE VEHICLE. BECAUSE OF PECULIAR CIRCUMSTANCES OF EACH CRASH AND ITS SEVERITY, THE RESTRAINT SYSTEM MAY GIVE ONLY MINIMAL PROTECTION.


Each Set of Zamp Arm Restraints includes:

- Two (2) Arm Restraint Straps
- Two (2) Mounting Straps



ARM RESTRAINT INSTRUCTIONS:

1. Place the Arm Restraint Strap around the bicep, above the elbow and below the shoulder (see *fig A*), making sure Zamp logo is facing out and right side up.
2. Thread the webbing of the Arm Restraint Strap through the D-rings on the opposite side of the Arm Restraint strap (*fig. B*), then thread the webbing back through one of the D-rings to secure the Arm Restraint around the forearm. Pull the webbing so the Restraint fits snugly.
3. Thread the flat end of the Mounting Strap through the open D-rings on the Arm Restraint (*fig. C*), then thread the strap back through one of the D-rings to secure the Mounting Strap to the Arm Restraint.
4. Connect the Mounting Strap to your racing harness by threading the shoulder buckle through the looped end of the Mounting Strap (*fig. D*) and inserting into the cam lock/latch of the racing harness.
5. Finally, adjust the length of the Mounting Strap so controls are still within reach and arms are restricted from going outside the vehicle.



WARNING

THIS ARTICLE IS SOLD WITHOUT WARRANTY, EXPRESSED OR IMPLIED. NO WARRANTY OR REGISTRATION IS MADE AS TO THIS PRODUCT'S ABILITY TO PROTECT THE USER FROM ANY INJURY OR DEATH. THE USER ASSUMES THAT RISK.